

WM Hyde 1 lens removal and insert

1. Loosen the rimlock screws and press out the demo lenses as if the frame was a normal acetate frame. The rimlock will open slightly.



2. Mount the Prescription lenses.
3. The acetate can be gently heated to make it easier to mount the lenses, especially high-prescription lenses.
4. Remount the rimlock screws.