

Gail Spence nosepad arm remounting

1. Use flat nose pliers to hold the pins and twist the pins 15°- 20°.



2. Apply strong thread locker to the holes and insert the nose pad arm. Use pliers with nylon or plastic jaws to press the nose pad arms firmly into place. Let the thread locker cure a few hours before use.

